


## Unibar™ Centralizer

### Placement Details

The lowest Quick-Lock™ Unibar™ Centralizer should be installed approximately 1 foot from the end of the tendon/bar material. Each successive Quick-Lock™ Unibar™ Centralizer should be placed at no greater than 10-foot intervals. The upper Quick-Lock™ Unibar™ Centralizer should be placed approximately 1 foot below grout/concrete surface.



**Unibar Centralizer US Patent No. 10,151,113**

**Manufacturers of Quality Concrete Accessories**

501 E Main St. Arlington, TX 76010 • 817/277-3738 • 800/342-2409 • 817/275-2335 Fax •  
[www.pieresearch.com](http://www.pieresearch.com)